

PPX 271 Pole pruner



Documents

Engine

Starter assy and clutch

Tank and air filter

Trasmission rod

Pruner attachment

Carburetor WT-1150

Accessories




Illustration Engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61280293AR	Muffler cover			Grigio; Grey	
2	2	3893054R	Screw				
3	1	61282025E	Gasket set				
4	5	3891048R	Screw				
5	2	3891044R	Screw				
6	1	61290075A	Complete muffler				
7	1	3892001A	Screw				
8	1	61280008DR	Gasket				
9	1	61280206R	Gasket				
10	1	3055120	Spark plug				
11	1	61280005BR	Gasket				
12	2	61290045R	Piston ring				
13	2	093000167R	Ring				
14	1	61292031B	Piston assy Ø34				
15	1	61292032C	Complete cylinder				
16	1	61280185R	Cylinder cover			Arancio; Orange	
17	1	2318817R	Air purge				
18	1	61250253R	Stopper			Arancio; Orange	
19	3	3960087AR	Screw				
20	1	3050038R	Seal ring				
21	2	3034009R	Bearing				
22	1	3025019	Ring				
23	1	61290077	Set roller cage and washer				
24	1	3028013R	Key				
25	1	61280004R	Crankshaft				
26	1	61280292	Half crankcase set + screws				
27	1	3050039R	Seal ring				
28	3	3860096R	Screw				
29	1	61292033CR	Short block				

Illustration Starter assy and clutch




Illustration Starter assy and clutch

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2501010BR	Ignition coil				
2	1	61280164R	Spark plug cap				
3	1	50050127	Spring				
4	2	3891020R	Screw				
5	2	50160218AR	Spacer				
6	1	61280291AR	Cable				
7	1	3912009	Nut				
8	1	3916009R	Washer				
9	1	61280187R	Flywheel				
10	2	61070039R	Spring				
11	2	61070038R	Pawl		02/2017		
12	1	61370013R	Clutch driver	03/2017			
13	1	3960070AR	Screw				
14	1	094600054R	Washer				
15	1	61172004R	Complete pulley				
16	1	61070036R	Spring				
17	1	3833080R	Washer				
18	1	61070019AR	Starter rope				
19	1	56530018R	Starter handle				
20	1	072700089R	Bushing				
21	1	56530019	Spring				
22	1	56530020	Insert				
23	2	56530021	Washer				
24	1	61170060BR	Starter assy			Arancio; Orange	
25	1	61052008R	Screw				
26	3	3960045	Screw				
27	1	61280163R	Flange				
28	1	61280151A	Set spacer				
29	4	3918007R	Washer				
30	2	4138494	Spring				
31	1	61280135CR	Clutch				
32	2	3806040	Screw				
33	1	61280130R	Clutch drum				
34	1	3025019	Ring				
35	1	3035023R	Bearing				
36	1	61280177R	Starter case				
37	1	3893054R	Screw				
38	1	3024012R	Snap ring				
39	1	4161428R	Sleeve				
40	1	4161364	Bushing				
41	2	3801016R	Screw				
42	1	61010020	Adaptor				
43	1	61010021	Adaptor				
44	2	3914003R	Nut				
45	4	3891048R	Screw				
46	2	61370014R	Pawl				

Illustration Tank and air filter




Illustration Tank and air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	072700076CR	Gasket				
2	1	074000130C	Insulator				
3	1	072700077CR	Gasket				
4	2	3891048R	Screw				
5	1	61290087R	Tube				
6	1	2318654R	Carburetor WT-1150				
7	1	61280059CR	Gasket				
8	1	61280183R	Air filter support set				
9	2	3891063R	Screw				
10	1	61170016R	Air filter				
11	1	61290078A	Air filter cover				
12	1	61330040AR	Screw				
13	1	61282025E	Gasket set				
14	1	61280105	Band				
15	1	61070011AR	Breather valve				
16	1	61290088R	Tube				
17	1	3073018R	Tube				
18	1	61290089R	Breather fuel pipe				
19	1	4161211R	Bush				
20	1	61070079AR	Tank cap				
21	1	61070006R	Gasket				
22	1	094600450R	Fuel filter				
23	1	61110162BR	Bushing				
24	3	61070015R	Spacer				
25	1	61170041	Stand				
26	3	3891048R	Screw				
27	1	61282030AR	Tank				
28	3	3918005R	Washer				
29	3	3819006R	Washer				

Illustration Trasmission rod




Illustration Trasmision rod

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61222004AR	Tube				
2	1	63090067AR	Set transmission				
3	1	63090049	Bushing				
4	1	61220059R	Transmiss. assy				
5	1	61222007CR	Tube				
6	2	63090005R	Spring				
7	3	63090024BR	Support				
8	1	63090025A	Support				
9	1	63090018	Slide				
10	1	63090043	Shaft joint				
11	2	3024011R	Ring				
12	1	3024014R	Snap ring				
13	2	61222009A	Union joint kit				
14	1	4161619AR	Band				
15	1	61222008CR	Tube				
16	1	61380095B	Handle kit				
17	1	61380055AR	Lever				
18	1	61380056R	Throttle lever				
19	1	61380096	Lever group				
20	1	61280201R	Throttle cable				
21	1	61280227AR	Cable				
22	3	63090039BR	Washer				




Illustration Pruner attachment

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	004400959R	Nut				
2	1	W0000201	Gear case				
3	1	W0000202	Chain cover assy				
4	1	W0000203	Chain tensioner kit				
5	2	3034008R	Bearing				
6	1	W000105	Sprocket				
7	1	W000106	Washer				
8	1	3024017	Ring				
9	2	3801011R	Screw				
10	4	W000113	Screw				
11	2	W000112	Stud				
12	1	3801030R	Screw				
13	1	W0000204	Case				
14	1	W0000205	Bevel gear set				
15	1	3801008R	Screw				
16	1	3025018R	Ring				
17	1	W0000206	Bearing				
18	1	W0000207	Spring				
19	1	W0000208	Pin				
20	1	W000115	O-ring				
21	1	W000117	Bowl cap				
22	1	W0000209	Oil pump				
23	1	W0000210	Ring				
24	1	W0000211	Complete cap				
25	2	3801004	Screw				
26	1	W0000212	Screw				
27	2	3914003R	Nut				
28	2	3833073R	Washer				
29	1	3025022R	Ring				
30	1	W0000214	Ring				
31	1	W0000215	Ring nut				
32	1	W0000216	Screw				
33	1	W0000217	Shaft				
34	1	W0000213	Bushing				
35	1	W0000200	Bushing				
36	1	3801043	Screw				
37	1	W000118	Oil filter				




Illustration Carburetor WT-1150

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	2318778	Adjust. screw				
2	1	2318671	Repair kit				
3	1	2318654R	Carburetor WT-1150				









Illustration Accessories

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	4160463AR	Single harness				
2	1	63090050	Tool kit				
3	1	61220074	Labels kit				
4	1	30629019A	Chain .3/8" x .043" (1,1mm)				
5	1	63090030R	Bar 10" - 25 cm				
6	1	W000139	Bar cover				