


## Иллюстрация Starter assy and engine from 22/02/08

Ссылка №	Кол-во	Код артикула	Наименование
1	1	094600097A	Spark plug cap
2	1	301000379R	Ignition coil
3	2	094000097	Screw
4	2	3819005	Washer
5	2	3916004	Washer
6	1	301000342	Support
7	1	3818011A	Washer
8	1	3819013	Washer
9	1	320000028	Nut
10	2	004000436R	Pin
11	2	300000038R	Pawl
12	2	300000040	Spring
13	1	301000384R	Flywheel
14	1	301000003	Support
15	4	3801009	Screw
16	1	300000025	Gasket
17	1	300000022	Tank cap
18	1	301000348R	Starter assy
19	1	301000049	Felt
20	1	3055098	Ring
21	1	3049006R	O-ring
22	1	3055044A	Cock
23	1	300000026	Hose
24	1	301000346R	Fuel tank
25	2	3960073	Screw
26	1	2317013	Guard
27	1	093500397	Starter handle
28	1	4098073R	Starter rope
29	1	094600041AR	Screw
30	2	3960081	Screw
31	1	094600169	Spring
32	1	2317021R	Switch
33	1	004000132R	Spring
34	1	300000016R	Pulley
35	1	3918006	Washer
36	1	3801008	Screw
37	1	302000007C	Carburetor SHA14-12L
38	1	301000025A	Manifold
39	1	301000026	Gasket
40	1	3055101	Spark plug
41	4	3801013R	Screw
42	1	301000365A	Cylinder
43	1	375200078R	Gasket
44	2	004900061R	Ring
45	1	301000035R	Piston pin
46	2	004000015R	Piston ring d.40





## Иллюстрация Starter assy and engine from 22/02/08


---

Ссылка №	Кол-во	Код артикула	Наименование
47	1	301000375A	Piston assy Ø40
48	2	3050015AR	Seal ring
49	2	3034012R	Bearing
50	1	301000385R	Crankshaft
51	1	3037005	Bearing
52	1	301000047	Key
53	1	300000035	Gasket
54	1	301000357AR	Muffler
55	2	005400303	Screw
56	2	3819006	Washer
57	1	375200071	Muffler cover
58	1	301000408	Crankcase assy
59	4	3801066	Screw
61	1	301000113A	Gasket set
62	1	301000349	Cable
67	2	3960092AR	Screw

Иллюстрация Starter assy and engine till 21/02/08



1<sup>a</sup> serie  
1<sup>st</sup> series



## Иллюстрация Starter assy and engine till 21/02/08

Ссылка №	Кол-во	Код артикула	Наименование
1	1	094600097A	Spark plug cap
2	1	301000343R	Ignition coil
3	2	094000097	Screw
4	2	3819005	Washer
5	2	3916004	Washer
6	1	301000342	Support
7	1	3818011A	Washer
8	1	3819013	Washer
9	1	320000028	Nut
10	2	004000436R	Pin
11	2	300000038R	Pawl
12	2	300000040R	Spring
13	1	301000359R	Flywheel
14	1	301000003	Support
15	4	3801009	Screw
16	1	300000025	Gasket
17	1	300000022	Tank cap
18	1	301000348R	Starter assy
19	1	301000049	Felt
20	1	3055098	Ring
21	1	3049006R	O-ring
22	1	3055044A	Cock
23	1	300000026	Hose
24	1	301000346R	Fuel tank
25	2	3960073	Screw
26	1	2317013	Guard
27	1	093500397	Starter handle
28	1	4098073R	Starter rope
29	1	094600041AR	Screw
30	2	3960081	Screw
31	1	094600169	Spring
32	1	2317021R	Switch
33	1	004000132R	Spring
34	1	300000016R	Pulley
35	1	3918006	Washer
36	1	3801008	Screw
37	1	302000007C	Carburetor SHA14-12L
38	1	301000025A	Manifold
39	1	301000026	Gasket
40	1	3055101	Spark plug
41	4	3801013R	Screw
42	1	301000365A	Cylinder
43	1	375200078R	Gasket
44	2	004900061R	Ring
45	1	301000035R	Piston pin
46	2	004000015R	Piston ring d.40



## Иллюстрация Starter assy and engine till 21/02/08

---

Ссылка №	Кол-во	Код артикула	Наименование
47	1	301000375A	Piston assy Ø40
48	2	3050015AR	Seal ring
49	2	3034012R	Bearing
50	1	301000036AR	Crankshaft
51	1	3037005	Bearing
52	1	301000047	Key
53	1	300000035	Gasket
54	1	301000357AR	Muffler
55	2	005400303	Screw
56	2	3819006	Washer
57	1	375200071	Muffler cover
58	1	301000382	Crankcase assy
59	4	3801066	Screw
61	1	301000113A	Gasket set
62	1	301000349	Cable
63	1	301000126	Starter assy
64	1	301000010	Spring
65	1	301000011	Button
66	1	005000122	Starter handle
67	2	3960092	Screw
69	1	3026003	Ring
70	1	301000042	Screw
71	1	301000081	Piston assy Ø40
72	1	301000024R	Ignition coil
73	1	341000009	Guard
74	1	006000829	Washer
75	1	301000379R	Ignition coil
76	1	301000384R	Flywheel




# Иллюстрация Pump assembly and carburetor

## mod. SA30TL 1<sup>a</sup>serie 1<sup>st</sup>series

fino al  
till

jusq'à  
hasta

19 sett. '99





## mod. SA 30TLA


dal - from

depuis - desde

20 sett. '99





37  
optional



standard

26




## Иллюстрация Pump assembly and carburetor

Ссылка №	Кол-во	Код артикула	Наименование
1	1	320000001	Cover
2	1	3049019	O-ring
3	1	321000011	Gasket
4	1	321000002	Screw
5	1	321000046	Cover
6	15	3801015	Screw
7	4	3916005	Washer
8	1	310000010	Cap
9	1	3049018	O-ring
10	1	321000056A	Pump assy sa 30
11	1	321000009	Gasket
12	1	321000004	Seal ring
13	1	321000007	Impeller
14	1	321000006A	Volute
15	1	321000003	O-ring
16	3	341000004	Washer
17	3	3908032R	Screw
18	1	321000045	Cover
19	3	3912005	Nut
20	1	341000127	Frame kit
21	2	3819006	Washer
22	2	3801009	Screw
23	2	3806063	Screw
24	2	3819013	Washer
25	1	341000016A	Fittings set
26	1	341000017	Filter
27	1	321000052	Valve
28	1	321000051	Pump body
29	1	321000050	Cover
30	1	321000053	Cap
31	1	094500054	Gasket
32	1	321000049A	Cover
33	1	3049027	O-ring
34	1	3049028	O-ring
35	4	3960077	Screw
36	7	3801024	Screw
37	1	341000102	Fittings
38	1	300000074	Lever group
39	1	302000157	Valve
40	1	300000266	Bushing
41	1	300000267	Gasket
42	1	3801026	Screw
43	1	300000217	Fuel filter
44	1	300000216	Fittings
45	1	300000215	Screw
46	1	300000222R	Jet



mod. SA30TL 1<sup>a</sup>serie 1<sup>st</sup>series

fino al 19 sett. '99  
till jusqu'à hasta




mod. SA 30TLA



dal - from 20 sett. '99  
depuis - desde



37 optional



standard 25



## Иллюстрация Pump assembly and carburetor

---

Ссылка №	Кол-во	Код артикула	Наименование
47	1	300000225	Pin
48	1	302000156	Jet 58
49	1	300000198	Float
50	1	300000073	Gasket set
51	1	300000079	Tank
52	1	365200077	Air filter kit
53	2	3908005	Screw
54	1	034000013	Nut
55	1	300000221	Screw
56	1	300000220	Spring
57	1	300000195	Valve
58	1	300000226	Clamp
59	1	300000227	Spring
60	1	300000228	Pin
61	1	365200074R	Spring
63	2	365200072R	Filter
65	1	302000007C	Carburetor SHA14-12L
66	2	006000315	Washer