

G 44 TK COMFORT PLUS (K500) Lawnmower

Documents

Complete illustrated parts list

Cylinder head and valve

Cylinder and crankcase

Crankcase cover

Crankshaft and piston

Starter assy and flywheel

Carburetor

Air filter and muffler

Control lever

Tank

Illustration Complete illustrated parts list




Illustration Complete illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	66060398BR	Traction lever				
2	2	66070732	Wheel kit				
3	1	66070653R	Traction cable				
4	1	66100013	Guard				
5	1	3914006R	Nut				
6	1	66110371R	Knob				
7	1	66030038	Grommet				
8	1	66070466R	Lock				
9	1	66070233	Guard kit				
10	8	66070497R	Bearing				
11	1	66060421BR	Handlebar				
12	1	66070748	Axle kit				
13	2	66070317R	Tightening handle				
14	1	8202126R	Key				
15	2	66060231	Band				
16	2	3910015R	Screw				
17	4	3933032R	Nut				
18	1	66070437R	Left sprocket				
19	1	66070456R	Shutter		12/2016	Nero; Black	
19	1	66070519R	Shutter	01/2017		Arancio; Orange	
20	1	66072047R	Frame				
21	1	66070457R	Grassbag				
22	1	66070523R	Cover				
23	1	66110609	Kit spring				
24	1	66110026R	Deflector axle				
25	1	66100007AR	Deck		12/2016	Arancio; Orange	
25	1	66100233AR	Deck	01/2017		Grigio; Grey	
26	2	3916015R	Washer				
27	2	66070728R	Wheel cover				
28	1	3047038R	Belt				
29	1	66070450R	Pulley				
30	1	3022020R	Plug				
31	1	66070652R	Spring				
32	2	66070435R	Bushing				
33	1	3024012R	Snap ring				
34	7	3916008R	Washer				
35	2	66100012	Rod				
36	1	66070436R	Right sprocket				
37	1	66070013C	Rear axle				
38	3	3806076R	Screw				
39	1	66070755	Transmission				
40	2	011200035R	Screw				
41	1	66070018	Lever				
42	2	66070060	Wheel cover				
43	1	66030044	Spacer				
44	1	66070036R	Spring				

Illustration Complete illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	2	66070731	Wheel kit				
46	2	8202311R	Ring				
47	2	66070727R	Wheel cover				
48	1	66060010R	Roller				
49	1	66060316AR	Brake lever				
50	1	3906150R	Screw				
51	2	66060030R	Bushing				
52	1	66060108R	Engine break cable				
53	1	66060384R	Washer				
54	1	66030256R	Hub Ø22,2mm				
55	1	66100221R	Blade				
56	1	66070630	Grassbag kit				
57	2	66030039	Plate				
58	4	3960031R	Screw				
59	6	3801022R	Screw				
60	2	66030049	Support				
61	2	3045035R	Retainer washer				
62	2	3045034R	Retainer washer				
63	3	66070228R	Support				
64	1	66070099R	Spring				
65	1	66070133R	Support				
66	1	66070628A	Labels kit				
67	2	3064037	Washer				
68	1	66060425R	Handle kit				
69	2	66060381BR	Pin				
70	2	3024006	Snap ring				
71	1	66110127R	Mulching cap				
72	1	66070521R	Shutter				
73	1	66060164BR	Complete throttle				
74	1	3906053	Screw				
75	1	3916006R	Washer				
76	1	3914006R	Nut				
77	1	66070744	Support set				

Illustration Cylinder head and valve





Illustration Cylinder head and valve

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150368	Compensator				
2	2	L66150403	Slide				
3	1	L66150404	Camshaft assy				
4	1	L66150399	Washer				
5	1	3055123	Spark plug				
6	2	L66150396	Stud		10/2013		
6	2	L66150709	Stud	11/2013			
7	1	L66150215	Head comp.cylinder				
8	4	L66150005	Screw				
9	4	L66150393	Screw				
10	2	L66150350	Plug				
11	1	L66150394	Cover				
12	2	L66150398	Spring holder				
13	2	L66150366	Valves spring				
14	1	L66150400	Suction/exhaust valve kit				
15	2	L66150396	Stud		10/2013		
15	2	L66150708	Stud	11/2013			
16	1	L66150401	Plate				
17	2	L66150402	Equalizer rod				
18	1	L66150227	Gasket set	10/2013			
18	1	L66150723	Gasket set		11/2013		
19	1	66060414	19 x 21 mm wrench				
20	1	L66150471	Gasket				




Illustration Cylinder and crankcase

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150224	Crankcase assy				
2	1	L66150406	Tank shield				
3	2	L66150251	Screw				
4	1	L66150227	Gasket set		10/2013		
4	1	L66150723	Gasket set	11/2013			
5	1	L66150407	Stud				
6	2	L66150408	Stud				
7	1	L66150410	Reed valve				
8	1	L66150420	Spring				
9	1	L66150411	Screw				
10	1	L66150257	Spring				
11	1	L66150415	Flyweheel brake				
12	1	L66150413	Cap				
13	2	L66150414	Screw				
14	1	L66150353	Plug				
15	1	L66150419	Gasket				
16	1	L66150710	Tube	11/2013			
16	1	L66150229	Tube		10/2013		
17	1	L66150417	Governor arm shaft				
18	1	L66150035	Washer				
19	1	L66150409	Seal ring				




Illustration Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150230	Cover				
2	7	L66150452	Screw				
3	3	L66150453	Screw				
4	1	L66150454	Plate				
5	2	L66150455	Bushing				
6	1	L66150456	Screw				
7	1	L66150232	Packing, breather chamber				
8	1	L66150458	Oil cap assy				
9	1	L66150457	Governor				
10	1	L66150463	Gasket				
11	1	L66150462	Oil seal				
12	1	L66150354	Washer				
13	2	L66150357	Plug				
14	1	L66150723	Gasket set	11/2013			
14	1	L66150227	Gasket set		10/2013		
15	1	L66150352	Screw				






Illustration Crankshaft and piston

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150070	Piston ring set				
2	2	L66150372	Retainer washer				
3	1	L66150342	Piston pin				
4	1	L66150217A	Piston assy				
5	2	L66150078	Connecting rod bolt				
6	1	L66150421	Connecting rod cpl.				
7	1	L66150355	Bearing				
8	1	L66150423	Crankshaft				
9	1	L66150081	Key				
10	1	L66150424	Washer				







Illustration Starter assy and flywheel

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150233	Starter assy				
2	1	L66150425	Flywheel				
3	1	L66150426	Fan				
4	1	L66150147	Pulley				
5	1	L66150376	Nut				
6	1	L66150427	Spark plug cap				
7	1	L66150428	Engine stop wire				
8	1	L66150429	Ignition coil				
9	1	L66150416	Screw				
10	3	L66150240	Screw				
11	1	L66150713	Cover	11/2013			
11	1	L66150234	Cover		10/2013		
12	1	L66150259	Screw				
13	1	L66150260	Slide				
14	1	L66150270	Starter handle				
15	1	L66150269	Starter rope				
16	1	L66150266	Starter spring				
17	1	L66150265	Pulley				
18	2	L66150263	Pawl				
19	2	L66150264	Spring				
20	1	L66150262	Spring				
21	1	L66150261	Washer				





Illustration Carburetor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150433	Insulator				
2	1	L66150142A	Carburetor				
3	1	L66150714	Gasket				
4	1	L66150211	Repair kit				
5	1	L66150723	Gasket set	11/2013			
5	1	L66150227	Gasket set		10/2013		



6*




Illustration Air filter and muffler

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150443	Muffler assy		10/2013		
1	1	L66150719	Muffler assy	11/2013			
2	1	L66150445	Air filter		10/2013		
2	1	L66150715	Air filter	11/2013			
3	1	L66150255	Sponge		10/2013		
3	1	L66150716	Sponge	11/2013			
4	1	L66150717	Air filter kit	11/2013			
4	1	L66150250	Air filter kit		10/2013		
5	2	L66150113	Nut				
6	1	L66150227	Gasket set		10/2013		
6	1	L66150723	Gasket set	11/2013			
7	1	L66150185	Nut				






Illustration Control lever

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150168	Adjust. screw				
2	1	L66150169	Spring				
3	1	L66150170	Spring				
4	1	L66150468	Plate				
5	1	L66150172	Screw				
6	1	L66150470	Complete lever				
7	2	L66150464	Screw				
8	1	L66150236	Rod				
9	1	L66150237	Spring				
10	1	L66150461	Throttle rod				
11	1	L66150448	Spring				
12	1	L66150447	Control lever				
13	1	L66150382	Screw				
14	1	L66150185	Nut				




Illustration Tank

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150437	Cap				
2	1	L66150436	Complete tank				
3	1	L66150185	Nut				
4	1	L66150438	Washer				
5	1	L66150251	Screw				
6	1	L66150439	Filter				
7	1	L66150239	Stud				
8	1	L66150440	Clip				
9	2	L66150435	Clip				
10	1	L66150432	Tube				