

BCI 30 Brushcutter



Documents

[Complete illustrated parts list](#)

[Head Load&Go D.103](#)

Illustration Complete illustrated parts list




Illustration Complete illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	54042002R	Shaft joint set				
2	23	3893016AR	Screw				
3	1	54042001R	Handle kit				
4	1	54042003R	Throttle kit				
5	1	54042009R	Electrical parts				
6	1	54040016R	Switch				
7	1	54040055R	Tube Ø24				
8	1	54042004R	Handle kit				
9	1	3806056R	Screw				
10	1	54040033AR	Knob				
11	1	034000013R	Nut				
12	1	54040066	Engine cover				
13	1	54042008R	Complete motor				
14	1	54040054R	Plate				
15	2	3893013R	Screw				
16	1	3918013R	Washer				
17	1	54040053R	Disc (guard)				
18	1	54042007R	Guard kit				
19	1	4174275R	Blade				
20	1	54030002	Battery			40V - 5AH	
20	1	54030001	Battery			40V - 2,5AH	
21	1	54030007	Battery charger				
22	1	63149001	Head Load&Go				




Illustration Head Load&Go D.103

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	63100018R	Kit spring				
2	2	63140007R	Bushing				
3	1	63140008R	Nylon spool				
4	1	63140005R	Knob				
5	1	63140006R	Lower cover				
6	1	63149001	Head Load&Go				